

4.5 Access to unit information

CYPRES 2 provides an easy way to view

1. the flight counter,
2. the units serial number,
3. the next maintenance date*
4. the scale meter or feet
5. the user selected activation altitude

To view the unit informations press the button immediately when the **0** appears at the end of the switch-on procedure and hold it.

Each value is displayed for 5 seconds, then the next value shows up.


You can stop the information sequence whenever you want by just releasing the button.

* After the 8 year maintenance has been performed, the words 'maint. no' and the date of the total lifetime (end of life) is shown.


1. display of the flight counter



2. display of the serial number



3. next maintenance due in 09 / 2016



4. display of the scale feet (meter)



5. user selected activation altitude setting

